

PACKAGE CONTENTS:

- BLUE Star Saber
- RED Star Saber
- User's Guide/Warranty Card
- Registration Card

SET UP:

- Insert 2 "AAA" batteries into the battery compartment located on the back of each Star Saber handle.
- Slide the latches on both sides of the Star Saber upward to unlock the opening for the remote.
- Once both latches are unlocked, pull down the back of the Star Saber handle and insert the Nintendo Wii Remote. Align the Wii Remote buttons with the appropriate openings in the front of the Star Saber handle.
- Close the Star Saber handle over the Wii Remote and slide the latches downward into the locked position.
- Power the Star Saber ON or OFF with the power button located on the front of the handle.

NOTE: Always practice safety first. When you are swinging the Twin Star Sabers, be aware of your surroundings, making sure not to hit anyone or anything. To prevent injury and property damage, make sure the Wii Remote is properly and securely attached to your Star Saber and that you are a reasonable distance from your television and any people around you. The Twin Star Sabers are accessories designed for gaming ONLY and should never be used to strike people, objects or other accessories. Always use your Wii Remote wrist straps when using the Twin Star Sabers.

TROUBLESHOOTING:

Problem: The Star Saber handle will not stay closed.

Solution: Make sure that the latches on both sides of the Star Saber handle are in the locked position.

Problem: The Star Saber will not illuminate.

Solution: Make sure that the Star Saber is powered ON. Make sure that there are batteries in the battery compartment. Make sure that the batteries are fresh and inserted properly and securely.

DISCLAIMER: dreamGEAR is NOT responsible for any personal injury or damage to property when using this product. It is the user's responsibility to practice proper safety procedures.

